


L2(W) plus Spare Parts List


L2(W)
Spare parts list



L2(W)


Spare parts list

Pos. No.	Order no.	Notes.	Pos. No.	Order no.	Notes.
1	6820-01	L2			
1	6820-20	L2W			
2	6840-01				
3	6340-05				
4	6841-05				
5	6875-01				
6	9990-43				
7		M6x25			
8	6840-25				
9	6381-13				
10	6840-21				
11	6381-18				
12	6381-17				
13	6381-16				
14		M6			
15		D6/12			
16		D8/15/3			
17		M6x16			
18	6840-20				
19	6871-01	Left			
20	6871-02	Right			
21		D8/17			
22		M8x16			
23	6871-10				
24		M8			
25		M8x20			
26	6874-03				
27	4474-02				
28		M6x12			
29	4473-02				
30	4473-01				
31	9985-27	Lgt. 710 mm			
32	6320-04				
33	9938-74				
34	9990-08				
35	6350-12				
36	6830-05	Left			
37	6830-06	Right			
38	6830-15	Left			
39	6830-16	Right			
40	6830-12				
41	6830-18				
42	9990-12				
43	6980-72	L2W			
44	6980-73	L2W			



Pos. No.	Order no.	Notes.	Pos. No.	Order no.	Notes.
1	6822-30				
2	9942-33				
3	6220-25				
4	9964-77				
5	6320-29				
6		M20			
7	6220-26				
8		M16x30			
9		M12x25			
10		M8x60			
11	6220-34				
12		M16x120			
13		M16			
14	6220-30				
15	6822-45				
16	6220-33				
17	9937-45				
18	9950-05				
19	6220-35				
20	6220-36				
21	6820-30				
22	6822-46				
23	6820-20				
24		D17/30			
25		M8			
26	9936-27				
27	6220-37				
28	6220-38				
29		D13/24			
30	6220-27				

L2(W)
Spare parts list




Spare parts list

Pos. No.	Order no.	Notes.	Pos. No.	Order no.	Notes.
1	6810-04				
2	6311-30				
3	9943-32	Red			
4	6311-31				
5	9943-33	White			
6		M8			
7	6716-01				
8	6716-05				
9		M8x20			
10	6713-02				
11	6713-10				
12	6313-11				
13		D8/17			
14		M8x10			
15	6313-12				
16		M8x25			
17	4012-12				
18	4412-20	Big			
19	4412-21	Small			
20	6312-03	Left			
21	6312-04	Right			
22	4512-12				
23	6812-01				
24	6312-13				
25	6813-15				
26	6313-20				

L2(W)

Spare parts list



Spare parts list

Pos. No.	Order no.	Notes.	Pos. No.	Order no.	Notes.
1	6850-02	540/750 rpm	48		M12
2	4160-01	L-side/R-thread	49	9936-10	ø89,5
3	4160-02	R-side/L-thread	50	3263-15	
4	4056-10		51	3263-20	
5	4056-03		52	9936-09	ø94
6	4058-05	L-side/R	53	9990-90	
7	4058-06	R-side/L	54	3263-11	
8	4161-02	L-side/R-thread	55	3263-12	
9	4161-01	R-side/L-thread	56	9931-10	
10		M6x10	57	9936-49	38x52x7
11		M8x10	58	3263-13	
12	4158-05		59		M12x45
13	4158-10		60		M12x35
14	4560-01	ø20xø30x5	61	9985-84	
15		M8	62	4470-01	
16		D8/17	63	9934-02	
17		M8x20	64	4653-02	
18	4550-05	Left	65	9931-15	
19	4550-06	Right	66	9990-99	14x20x10
20		ø8x40	67	4660-00	
21		ø5x40	68	9936-29	14x22x4
22	4051-05		69	9936-28	
23	9936-37	35x62x12	70	9937-13	U 14
24	9950-02	6305-2RS	71		M8
25		M8x16	72		M8x20
26	4454-05		73		M8x10
27	4155-04	Right thread	74	4655-05	
28		ø8x45	75	4653-15	
29		ø5x45	76		D6/17/3
30	3265-02	15 teeth	77		M6x16
31	3262-05		78	9990-26	
32	3260-04		79	6850-11	
33		M10x25	80		D8/16
34	3260-05		81	9934-31	
35	9937-40	I 60	82	6350-08	
36		M12x35	83	9934-07	
37		D12/24	84	4690-05	
38		M12	85		M6x20
39	4457-02		86		D6/12
40	4456-02		87		M6
41	9931-56	8x7x25	88	4650-12	E1-T 2 Left / 2 Right
42	4652-11	17/24 teeth	88	4650-20	E2-T 2 Left / 2 Right
43	4652-08		88	4650-75	E6-T 2 Left / 2 Right
44	4652-03		88	4650-50	U1-T 2 Left / 2 Right
45	4062-05	Left thread	89	3263-10	
46	9950-03	6206-2RS	90	4750-50	
47	4652-01				

Spare parts list

Notes:

[illegible]

Spare parts list

Notes:

[illegible]

Spare parts list

Notes:

[illegible]